






Instructions Manual





Double Adjustable Hook Mountings


Serial No.	Definition	Picture	Size(MM)	Remarks
1	ING-SEC-35		40	
2	ING-SMC-35		40	
3	ING-STR-SPA		140	
4	ING-STR-1200		1200	
5	ING-TRH-WDA180		140	
6	ING-STR-SC		40	


2. Installation Diagram









A
B
5
C


M10*25
M10
A



M10*25
M10
B



ST6. 3*65
C







2.1 Installation for Triangular Mountings：







2.2 Installation for Rails：








2.3 Installation for Modules：













2.4 Finish





3. Notice:

This installation is only applicable on our product. Please install strictly according to our providing install steps. We can not advise on other installation methods

1. Please do the necessary protective measures as power source is used under installation.
2. Product section is relatively sharp, please wear labor protection appliance to avoid your unnecessary injury.
3. In the construction of a number of people, please make instant communication to avoid accidental injury.
4. Tools Preparation

Serial No.	Tools Name	Purpose
1	M8 Inner Hexagon Spanner	Using during installation of Mid Clamp, End Clamp, Rail Splicer, Rail Clamp
2	M18 Hexagon Spanner	Using during installation of Rail Clamp
3	M10 Hexagon Spanner	Using during installation of hook Screws (M10*25)
4	Socket Wrench	Using during installation of hook Screws (ST6.3*65)
5	Gloves, Safety hat, Protective eyewear, Safe Belt, Safety Footwear, Insulated Gloves and other necessary Safety Products.	