

GL-FL150 Series

User's Manual

Thank you for choosing the GL-FL150 Series LED products.

Please install and use the products according to the following directions to ensure normal function and operation.


Please use stainless screw to fix holder and make sure screwed tightly.

Please do not add/remove any electrical components to/from the products or change/tamper the original electrical design without our permission.

Please do not add/remove any mechanical components to/from the products or change/tamper the original mechanical design without our permission.

If you do not follow these instructions to properly install and use the GL-FL150 Series, you will not be eligible for warranty compensation or protection.

We do not take any responsibility for product damage resulting from improper installation or abnormal usage.




Installation Steps

The set up process should be executed by qualified (Certified) engineers.


Step 1.

Before installation, please turn off the power switch.



Step 2.

Connect the fixture's power cables to their corresponding colors of the power source and entwine together. Connect the grounding line to the grounding screw of the grounding devices.





⊕ Grounding line should be fixed perpetually and not allow to disconnect.




Step 3.

Screw the LED fixture tight onto a wall or a stand and adjust the angle in accordance with individual needs.

* Please use stainless screw to fix holder and make sure screwed tightly.



GL-FL150 Outlook



Net Weight:
5.25 Kg(with driver & lampshade)

UNIT:mm

Notices

1. Avoiding improper use to exceed the criterion limitation of lamp operation temperature.
2. Allow lamp to cool before replacing.
3. Not suitable for dimming function.

CAUTIONS

1. If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.
2. Prior to installation, remove the AC power.

